



Low Voltage Wall Mount Touch CCT Controller

MODEL: LT-031-W

Product Specifications

Summary

The Low Voltage Wall Mount Touch CCT (Correlated Colour Temperature) Controller features both colour temperature and brightness adjustment functions for dual colour LEDs (warm white and cool white). It combines the simplicity to use with the convenience of wall mounting and easy installation.

Technical Parameters

- Working temperature: -20-60°
- Supply voltage: 12V/24V DC
- Output voltage: 12V/24V DC
- Output: 2 channels
- Connection mode: common anode
- External dimension: L74 X W120X H41.8mm
- Packing size: L150 X W100X H57mm
- Net weight: 126g
- Gross weight: 188g
- Static power consumption: <1W
- Output current: <4A(each channel)
- Output power: 12V<96W,24V<192W



Safety Instructions

1. Save these instructions.
2. Read all instructions thoroughly before commencing assembly or installation.
3. For indoor use only.
4. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
5. Use only Class 2 non-dimmable power supplies.
6. Turn off all electrical power before modifying lighting system in any way.

Interface Specifications

Ports 1, 2, 3: output ports to connect LED lights (1-warm white, 2-cool white, 3- (+)12V/24V DC).

Ports 4, 5: Input 12V/24V DC.



Front Panel Specifications



Adjust colour temperature.



Turn on/off LED light in any state.




Reduce brightness.




Increase brightness.

Typical Application



External Dimensions



Installation

1. WIRING

Connect wires (load side first) as follows:

Ports 1, 2, 3: output ports to connect LED lights (1-warm white, 2-cool white, 3- (+)12V/24V DC).


Ports 4, 5: Input 12V/24V DC.

Note: Use only Class 2, non-dimmable power supplies.



2. OPEN THE PANEL


Using a flat screwdriver, gently pry open the panel back.



3. INSTALL PANEL BASE


Step 1:

On the front panel, pull the edges of the black insert of the connector (marked with red circles), and remove the ribbon cable.




Step 2:

Mount the panel base into the 2X4 switch or utility box.



4. MOUNT THE FRONT PANEL

Re-connect the ribbon cable (blue side up), and mount the controller front panel.



Notes

1. Use only Class 2, non-dimmable 24V DC power supplies.
2. Please avoid short-circuits during installation.